



INSTALLATION INSTRUCTIONS



DOOR COVER PANELS
APPLICATION:
2018-2020 Ford F150 Police Responder
PART NUMBER:
FF150-DC

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1,2	2	DOOR COVER PANEL, DRIVER (1) AND PASSENGER(2)	DRILL MOTOR
3	14	PANEL FASTENERS	1/4" DRILL BIT
ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING			
			
ITEM 1		ITEM 2	

PROCEDURE

1. Remove contents from box, verify if all parts listed are present and free from damage.
Carefully read and understand all instructions before attempting installation.
Failure to identify damage before installation could lead to a rejection of any claim.
2. Position the Door Cover Panel (1-2) onto the corresponding door of the vehicle.
3. Once the desired position is determined, mark the 8 holes of the Door Cover Panel (1-2) onto the door for drilling.
4. Using a 1/4" drill bit, drill out the marked holes. *Note: Do not drill through more than an inch to avoid damaging internal components in the door.* See **Figure 1**.
5. After drilling all of the holes, fasten the Door Cover Panel (1-2) using the provided Panel Fasteners (3). See **Figure 2**.



Drill out the holes using the cover panel as a template.

Fig 1

Insert a Panel Fastener into each hole and into the door.



Fig 2

INSTALLATION COMPLETE





WARNING



Failure to follow these instructions could lead to death, personal injury, and / or property damage.

Failure to follow these instructions could lead to death, personal injury, and / or property damage.

FASTENERS:

All supplied fasteners must be utilized and installed in accordance with the installation instructions and apply torque to the specifications as defined. **DOUBLE CHECK ALL FASTENERS BEFORE INITIAL USE, AND PERIODICALLY IN THE FUTURE TO ENSURE PROPER FUNCTION AND SAFETY.**

DRILLING:

Most Laguna products do not require drilling for installation. If drilling is defined as required, use caution when drilling a vehicle. **FAILURE TO REVIEW AN AREA TO BE DRILLED MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.**

EYE PROTECTION:

ALWAYS WEAR SAFETY GLASSES OR GOGGLES DURING THE INSTALLATION PROCESS TO AVOID PERSONAL INJURY.

FOR CALIFORNIA RESIDENTS ONLY-PROP 65 WARNING:

Some products may contain chemicals such as DEHP, which can cause cancer, birth defects or other reproductive harm. For more info go to www.p65warnings.ca.gov
